



DEEP SEA ELECTRONICS PLC DSE4510 / DSE4520 Operator Manual

Document Number: 057-171

Author: Allan Jones

DEEP SEA ELECTRONICS PLC



Highfield House
Hunmanby
North Yorkshire
YO14 0PH
ENGLAND

Sales Tel: +44 (0) 1723 890099
Sales Fax: +44 (0) 1723 893303

E-mail : sales@deepseapl.com
Website : www.deepseapl.com

DSE4510/DSE4520 Operator Manual

© Deep Sea Electronics Plc

All rights reserved. No part of this publication may be reproduced in any material form (including photocopying or storing in any medium by electronic means or other) without the written permission of the copyright holder except in accordance with the provisions of the Copyright, Designs and Patents Act 1988.

Applications for the copyright holder's written permission to reproduce any part of this publication should be addressed to Deep Sea Electronics Plc at the address above.

The DSE logo is a UK registered trademarks of Deep Sea Electronics PLC.

Any reference to trademarked product names used within this publication is owned by their respective companies.

Deep Sea Electronics Plc reserves the right to change the contents of this document without prior notice.

Amendments List

| Issue | Comments | Minimum Module version required | Minimum Configuration Suite Version required |
|-------|-----------------------------------|--|--|
| 1 | Initial release | V1.0.0 | |
| 2 | Added FPE item 11 – Display ph-ph | V1.0.0 | |
| | | | |
| | | | |
| | | | |
| | | | |

Typeface: The typeface used in this document is *Arial*. Care should be taken not to mistake the upper case letter I with the numeral 1. The numeral 1 has a top serif to avoid this confusion.

Clarification of notation used within this publication.**NOTE:**

Highlights an essential element of a procedure to ensure correctness.

**CAUTION!**

Indicates a procedure or practice, which, if not strictly observed, could result in damage or destruction of equipment.

**WARNING!**

Indicates a procedure or practice, which could result in injury to personnel or loss of life if not followed correctly.

TABLE OF CONTENTS

| Section | Page |
|--|-------------|
| 1 BIBLIOGRAPHY | 6 |
| 1.1 INSTALLATION INSTRUCTIONS..... | 6 |
| 1.2 MANUALS | 6 |
| 1.3 TRAINING GUIDES | 6 |
| 1.4 THIRD PARTY DOCUMENTS..... | 6 |
| 2 INTRODUCTION | 7 |
| 3 SPECIFICATIONS..... | 8 |
| 3.1 PART NUMBERING | 8 |
| 3.1.1 SHORT NAMES..... | 8 |
| 3.2 TERMINAL SPECIFICATION | 9 |
| 3.3 POWER SUPPLY REQUIREMENTS | 9 |
| 3.4 GENERATOR VOLTAGE / FREQUENCY SENSING | 9 |
| 3.5 GENERATOR CURRENT SENSING | 10 |
| 3.5.1 VA RATING OF THE CTS | 11 |
| 3.5.2 CT POLARITY | 12 |
| 3.5.3 CT PHASING | 12 |
| 3.5.4 CT CLASS | 12 |
| 3.6 INPUTS | 13 |
| 3.6.1 DIGITAL INPUTS..... | 13 |
| 3.6.2 ANALOGUE INPUTS..... | 13 |
| 3.6.2.1 OIL PRESSURE | 13 |
| 3.6.2.2 COOLANT TEMPERATURE | 13 |
| 3.6.2.3 FLEXIBLE SENSOR..... | 14 |
| 3.6.2.4 CHARGE FAIL INPUT | 14 |
| 3.7 OUTPUTS | 14 |
| 3.7.1 OUTPUTS A & B..... | 14 |
| 3.7.2 CONFIGURABLE OUTPUTS C,D,E & F (E & F 4520 ONLY) | 14 |
| 3.8 COMMUNICATION PORTS | 15 |
| 3.9 COMMUNICATION PORT USAGE | 15 |
| 3.9.1 CAN INTERFACE | 15 |
| 3.9.2 USB CONNECTION | 16 |
| 3.10 ACCUMULATED INSTRUMENTATION..... | 16 |
| 3.11 DIMENSIONS AND MOUNTING | 17 |
| 3.11.1 DIMENSIONS | 17 |
| 3.11.2 PANEL CUTOUT | 17 |
| 3.11.3 WEIGHT | 17 |
| 3.11.4 FIXING CLIP | 17 |
| 3.11.5 SILICON SEALING GASKET | 18 |
| 3.12 APPLICABLE STANDARDS | 19 |
| 3.12.1 ENCLOSURE CLASSIFICATIONS..... | 20 |
| 3.12.2 NEMA CLASSIFICATIONS..... | 21 |
| 4 INSTALLATION | 22 |
| 4.1 TERMINAL DESCRIPTION | 22 |
| 4.1.1 DC SUPPLY, FUEL AND START OUTPUTS, OUTPUTS C,D,E & F | 23 |
| 4.1.2 ANALOGUE SENSOR..... | 23 |
| 4.1.3 CONFIGURABLE DIGITAL INPUTS | 24 |
| 4.1.4 CAN | 24 |
| 4.1.5 GENERATOR / MAINS VOLTAGE SENSING | 24 |
| 4.1.6 GENERATOR CURRENT TRANSFORMERS | 25 |
| 4.1.7 PC CONFIGURATION INTERFACE CONNECTOR..... | 26 |
| 4.2 TYPICAL WIRING DIAGRAMS | 27 |
| 4.2.1 DSE4510 AUTOSTART MODULE | 28 |
| 4.2.2 DSE4520 AUTO MAINS FAILURE MODULE..... | 29 |

| | | |
|-----------|--|-----------|
| 5 | MODULE DISPLAY | 30 |
| 5.1 | INSTRUMENTATION ICONS | 30 |
| 5.2 | ACTIVE CONFIGURATION | 31 |
| 5.3 | MODE ICON | 31 |
| 5.4 | AUTO RUN ICON | 31 |
| 5.5 | BACKLIGHT | 31 |
| 5.6 | FAULT ICONS | 32 |
| 6 | DESCRIPTION OF CONTROLS | 33 |
| 6.1 | QUICKSTART GUIDE | 34 |
| 6.1.1 | STARTING THE ENGINE | 34 |
| 6.1.2 | STOPPING THE ENGINE | 34 |
| 6.2 | VIEWING THE INSTRUMENT PAGES | 35 |
| 6.2.1 | MENU | 35 |
| 6.2.2 | HOME | 36 |
| 6.2.3 | GENERATOR | 36 |
| 6.2.4 | MAINS (DSE4520 ONLY) | 36 |
| 6.2.5 | ENGINE | 36 |
| 6.2.6 | INFO | 36 |
| 6.2.7 | ENGINE DTC | 37 |
| 6.2.8 | EVENT | 37 |
| 7 | OPERATION | 38 |
| 7.1 | CONTROL PUSH-BUTTONS | 38 |
| 7.2 | STOP MODE | 39 |
| 7.2.1 | ECU OVERRIDE | 40 |
| 7.3 | AUTOMATIC MODE | 41 |
| 7.3.1 | WAITING IN AUTO MODE | 41 |
| 7.3.2 | STARTING SEQUENCE | 41 |
| 7.3.3 | ENGINE RUNNING | 41 |
| 7.3.4 | STOPPING SEQUENCE | 42 |
| 7.4 | MANUAL MODE | 43 |
| 7.4.1 | WAITING IN MANUAL MODE | 43 |
| 7.4.2 | STARTING SEQUENCE | 43 |
| 7.4.3 | ENGINE RUNNING | 44 |
| 7.4.4 | STOPPING SEQUENCE | 44 |
| 7.5 | MAINTENANCE ALARM | 45 |
| 8 | SCHEDULER | 46 |
| 8.1.1 | STOP MODE | 46 |
| 8.1.2 | AUTO MODE | 46 |
| 9 | FRONT PANEL CONFIGURATION | 47 |
| 9.1 | ACCESSING THE FRONT PANEL CONFIGURATION EDITOR | 48 |
| 9.1.1 | EDITING A PARAMETER | 49 |
| 9.2 | ADJUSTABLE PARAMETERS | 50 |
| 9.3 | PRE-COMMISSIONING | 57 |
| 10 | FAULT FINDING | 58 |
| 10.1 | CAN | 59 |
| 10.2 | INSTRUMENTS | 59 |
| 10.3 | MISCELLANEOUS | 60 |
| 11 | MAINTENANCE, SPARES, REPAIR AND SERVICING | 61 |
| 11.1 | PURCHASING ADDITIONAL CONNECTOR PLUGS FROM DSE | 61 |
| 11.1.1 | PACK OF PLUGS | 61 |
| 11.1.2 | INDIVIDUAL PLUGS | 61 |
| 11.2 | PURCHASING ADDITIONAL FIXING CLIPS FROM DSE | 61 |
| 11.3 | PURCHASING ADDITIONAL SEALING GASKET FROM DSE | 61 |
| 12 | WARRANTY | 62 |

| | | |
|-----------|--|-----------|
| 13 | DISPOSAL | 62 |
| 13.1 | WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT) | 62 |
| 13.2 | ROHS (RESTRICTION OF HAZARDOUS SUBSTANCES)..... | 62 |

1 BIBLIOGRAPHY

This document refers to and is referred to by the following DSE publications which can be obtained from the DSE website: www.deepseapl.com

1.1 INSTALLATION INSTRUCTIONS

Installation instructions are supplied with the product in the box and are intended as a 'quick start' guide only.

| DSE PART | DESCRIPTION |
|----------|---|
| 053-145 | DSE4510/DSE4520 Installation Instructions |

1.2 MANUALS

Product manuals are can be downloaded from the DSE website: www.deepseapl.com

| DSE PART | DESCRIPTION |
|----------|--|
| 057-004 | Electronic Engines and DSE Wiring |
| 057-172 | DSE4500 Series Configuration Software Manual |

1.3 TRAINING GUIDES

Training Guides are produced to give 'handout' sheets on specific subjects during training sessions

| DSE PART | DESCRIPTION |
|----------|-----------------------------|
| 056-005 | Using CTs With DSE Products |
| 056-010 | Overcurrent Protection |
| 056-022 | Breaker Control |
| 056-029 | Smoke Limiting |
| 056-030 | Module PIN Codes |

1.4 THIRD PARTY DOCUMENTS

The following third party documents are also referred to:

| REFERENCE | DESCRIPTION |
|--------------------|---|
| ISBN 1-55937-879-4 | IEEE Std C37.2-1996 IEEE Standard Electrical Power System Device Function Numbers and Contact Designations. Institute of Electrical and Electronics Engineers Inc |
| ISBN 0-7506-1147-2 | Diesel generator handbook. L.L.J.Mahon |
| ISBN 0-9625949-3-8 | On-Site Power Generation. EGSA Education Committee. |

Product manuals are can be downloaded from the DSE website: www.deepseapl.com

2 INTRODUCTION

This document details the installation and operation requirements of the DSE4500 Series modules, part of the DSEgenset® range of products.

The manual forms part of the product and should be kept for the entire life of the product. If the product is passed or supplied to another party, ensure that this document is passed to them for reference purposes.

This is not a *controlled document*. You will not be automatically informed of updates. Any future updates of this document will be included on the DSE website at www.deepseapl.com

The DSE4500 series is designed to provide differing levels of functionality across a common platform. This allows the generator OEM greater flexibility in the choice of controller to use for a specific application.

The DSE4500 series module has been designed to allow the operator to start and stop the generator, and if required, transfer the load to the generator automatically. Additionally, the DSE4520 automatically starts and stops the generator set depending upon the status of the mains (utility) supply. The user also has the facility to view the system operating parameters via the LCD display.

The DSE4500 module monitors the engine, indicating the operational status and fault conditions, automatically shutting down the engine and giving a true first up fault condition of an engine. The LCD display indicates the fault.

The powerful ARM microprocessor contained within the module allows for incorporation of a range of complex features:

- *Icon based LCD display*
- **True RMS** Voltage, Current monitoring (4510-02 and 4520-02 only)
- *USB Communications*
- *Engine parameter monitoring.*
- *Fully configurable inputs for use as alarms or a range of different functions.*
- *Engine ECU interface to **electronic engines**.*

Using a PC and the DSE Configuration Suite software allows alteration of selected operational sequences, timers, alarms and operational sequences. Additionally, the module's integral front panel configuration editor allows adjustment of this information.


A robust plastic case designed for front panel mounting houses the module. Connections are via locking plug and sockets.

Access to critical operational sequences and timers for use by qualified engineers, can be protected by a security code. Module access can also be protected by PIN code. Selected parameters can be changed from the module's front panel.

The module is housed in a robust plastic case suitable for panel mounting. Connections to the module are via locking plug and sockets.

3 SPECIFICATIONS

3.1 PART NUMBERING




At the time of this document production, there have been no revisions to the module hardware.

3.1.1 SHORT NAMES

| Short name | Description |
|-----------------|-----------------------------------|
| DSE4000,DSE45xx | All modules in the DSE4000 range. |
| DSE4500,DSE45xx | All modules in the DSE4500 range. |
| DSE4510 | DSE4510 module/controller |
| DSE4520 | DSE4520 module/controller |

3.2 TERMINAL SPECIFICATION

| | | |
|--------------------|---|--|
| Connection type | Two part connector. <ul style="list-style-type: none"> Male part fitted to module Female part supplied in module packing case - Screw terminal, rising clamp, no internal spring. |  <p>Example showing cable entry and screw terminals of a 10 way connector</p> |
| Minimum cable size | 0.5mm ² (AWG 24) | |
| Maximum cable size | 2.5mm ² (AWG 10) | |

NOTE: For purchasing additional connector plugs from DSE, please see the section entitled Maintenance, Spares, Repair and Servicing elsewhere in this document.

3.3 POWER SUPPLY REQUIREMENTS

| | |
|---|--|
| Minimum supply voltage | 8V continuous |
| Cranking dropouts | Able to survive 0V for 100mS providing the supply was at least 10V before the dropout and recovers to 5V afterwards. |
| Maximum supply voltage | 35V continuous (60V protection) |
| Reverse polarity protection | -35V continuous |
| Maximum operating current | 85mA at 12V 96mA at 24V |
| Maximum standby current | 47mA at 24V 51mA at 12V |
| Maximum Current when in Sleep Mode | 35mA @ 12V 32mA @ 24V |
| Maximum Current when in Deep Sleep Mode | < 10µA@12V < 10µA@24V |

Plant supply instrumentation display

| | |
|------------|---|
| Range | 0V-70V DC (note Maximum continuous operating voltage of 35V DC) |
| Resolution | 0.1V |
| Accuracy | 1% full scale (±0.7V) |

3.4 GENERATOR VOLTAGE / FREQUENCY SENSING

| | |
|-------------------------------|--|
| Measurement type | True RMS conversion |
| Sample Rate | 5KHz or better |
| Harmonics | Up to 11 th |
| Input Impedance | 300K Ω ph-N |
| Phase to Neutral | 15V to 415V AC (absolute maximum) |
| Phase to Phase | 25V to 720V AC (absolute maximum) |
| Common mode offset from Earth | 100V AC (max) |
| Resolution | 1V AC phase to neutral 2V AC phase to phase |
| Accuracy | $\pm 1\%$ of full scale phase to neutral $\pm 2\%$ of full scale phase to phase |
| Minimum frequency | 3.5Hz |
| Maximum frequency | 75.0Hz |
| Frequency resolution | 0.1Hz |
| Frequency accuracy | $\pm 0.2\text{Hz}$ |

3.5 GENERATOR CURRENT SENSING



NOTE: Current Sensing is not available on models 4510-01 and 4520-01.

| | |
|-----------------------------|---|
| Measurement type | True RMS conversion |
| Sample Rate | 5KHz or better |
| Harmonics | Up to 10 th or better |
| Nominal CT secondary rating | 5A |
| Maximum continuous current | 5A |
| Overload Measurement | 3 x Nominal Range setting |
| Absolute maximum overload | 50A for 1 second |
| Burden | 0.25VA (0.01 Ω current shunts) |
| common mode offset | $\pm 1\text{V}$ peak plant ground to CT common terminal |
| Resolution | 0.5% of 5A |
| Accuracy | $\pm 1\%$ of Nominal (1A or 5A) (excluding CT error) |

3.5.1 VA RATING OF THE CTS


The VA burden of the module on the CTs is 0.5VA. However depending upon the type and length of cabling between the CTs and the module, CTs with a greater VA rating than the module are required.

The distance between the CTs and the measuring module should be estimated and cross-referenced against the chart opposite to find the VA burden of the cable itself.

If the CTs are fitted within the alternator top box, the star point (common) of the CTs should be connected to system ground (earth) as close as possible to the CTs. This minimises the length of cable used to connect the CTs to the DSE module.

Example.

If 1.5mm² cable is used and the distance from the CT to the measuring module is 20m, then the burden of the cable alone is approximately 15VA. As the burden of the DSE controller is 0.5VA, then a CT with a rating of at least $15 + 0.5 = 15.5\text{VA}$ must be used. If 2.5mm² cables are used over the same distance of 20m, then the burden of the cable on the CT is approximately 7VA. CT's required in this instance is at least 7.5VA (7+0.5).




NOTE: Details for 4mm² cables are shown for reference only. The connectors on the DSE modules are only suitable for cables up to 2.5mm².

3.5.2 CT POLARITY

Take care to ensure the correct polarity of the CTs. Incorrect CT orientation will lead to negative kW readings when the set is supplying power. Take note that paper stick-on labels on CTs that show the orientation are often incorrectly placed on the CT (!). It is more reliable to use the labelling in the case moulding as an indicator to orientation (if available).

To test orientation, run the generator in island mode (not in parallel with any other supply) and load the generator to around 10% of the set rating. Ensure the DSE module shows positive kW for all three individual phase readings.



NOTE: Take care to ensure correct polarity of the CT primary as shown above. If in doubt, check with the CT supplier.

3.5.3 CT PHASING

Take particular care that the CTs are connected to the correct phases. For instance, ensure that the CT on phase 1 is connected to the terminal on the DSE module intended for connection to the CT for phase 1.

Additionally ensure that the voltage sensing for phase 1 is actually connected to generator phase 1. Incorrect connection of the phases as described above will result in incorrect power factor (pf) measurements, which in turn results in incorrect kW measurements.

One way to check for this is to make use of a single-phase load. Place the load on each phase in turn, run the generator and ensure the kW value appears in the correct phase. For instance if the load is connected to phase 3, ensure the kW figure appears in phase 3 display and not in the display for phase 1 or 2.

3.5.4 CT CLASS

Ensure the correct CT type is chosen. For instance if the DSE module is providing overcurrent protection, ensure the CT is capable of measuring the overload level you wish to protect against, and at the accuracy level you require.

For instance, this may mean fitting a protection class CT (P10 type) to maintain high accuracy while the CT is measuring overload currents.

Conversely, if the DSE module is using the CT for instrumentation only (current protection is disabled or not fitted to the controller), then measurement class CTs can be used. Again, bear in mind the accuracy you require. The DSE module is accurate to better than 1% of the full-scale current reading. To maintain this accuracy you should fit Class 0.5 or Class 1 CTs.

You should check with your CT manufacturer for further advice on selecting your CTs

3.6 INPUTS

3.6.1 DIGITAL INPUTS

| | |
|-------------------------|---|
| Number | 4 configurable inputs |
| Arrangement | Contact between terminal and ground |
| Low level threshold | 3.2V minimum |
| High level threshold | 8.1V maximum |
| Maximum input voltage | +60V DC with respect to plant supply negative |
| Minimum input voltage | -24V DC with respect to plant supply negative |
| Contact wetting current | 6mA typical |
| Open circuit voltage | 15V typical |

3.6.2 ANALOGUE INPUTS

3.6.2.1 OIL PRESSURE

Configurable if engine ECU link provides oil pressure measurement

| | |
|-------------------------|--|
| Measurement type | Resistance measurement by measuring voltage across sensor with a fixed current applied |
| Arrangement | Differential resistance measurement input |
| Measurement current | 11mA 8.8mA@12V |
| Full scale | 240Ω |
| Over range / fail | 270Ω |
| Resolution | 0.1 Bar (1-2 PSI) |
| Accuracy | ±2% of full scale resistance (±4.8Ω) excluding transducer error |
| Max common mode voltage | ±2V |
| Display range | 13.7 bar (0-200 PSI) subject to limits of the sensor |

3.6.2.2 COOLANT TEMPERATURE

Configurable if engine ECU link provides coolant temp measurement

| | |
|-------------------------|--|
| Measurement type | Resistance measurement by measuring voltage across sensor with a fixed current applied |
| Arrangement | Differential resistance measurement input |
| Measurement current | 11mA |
| Full scale | 480Ω |
| Over range / fail | 540Ω |
| Resolution | 1°C (2°F) |
| Accuracy | +/-2% of full scale resistance (±9.6Ω) excluding transducer error |
| Max common mode voltage | ±2V |
| Display range | 0°C -140°C (32°F - 284°F) subject to limits of the sensor |

3.6.2.3 FLEXIBLE SENSOR

| | |
|-------------------------|--|
| Measurement type | Resistance measurement by measuring voltage across sensor with a fixed current applied |
| Arrangement | Differential resistance measurement input |
| Measurement current | 11mA \pm 10% |
| Full scale | 480 Ω |
| Over range / fail | 540 Ω |
| Resolution | 1% |
| Accuracy | \pm 2% of full scale resistance (\pm 9.6 Ω) excluding transducer error |
| Max common mode voltage | \pm 2V |
| Display range | 0-250% |

3.6.2.4 CHARGE FAIL INPUT

| | |
|-----------------|--------------------------------------|
| Minimum voltage | 0V |
| Maximum voltage | 35V (plant supply) |
| Resolution | 0.2V |
| Accuracy | \pm 1% of max measured voltage |
| Excitation | Active circuit constant power output |
| Output Power | 2.5W Nominal @12V and 24V |
| Current at 12V | 210mA |
| Current at 24V | 105mA |

The charge fail input is actually a combined input and output. Whenever the generator is required to run, the terminal provides excitation current to the charge alternator field winding. When the charge alternator is correctly charging the battery, the voltage of the terminal is close to the plant battery supply voltage. In a failed charge situation, the voltage of this terminal is pulled down to a low voltage. It is this drop in voltage that triggers the *charge failure* alarm. The level at which this operates and whether this triggers a warning or shutdown alarm is configurable using the DSE Config Suite Software.

3.7 OUTPUTS**3.7.1 OUTPUTS A & B**

| | |
|--------|--|
| Type | Normally used for Fuel / Start outputs. Fully configurable for other purposes if the module is configured to control an electronic engine. |
| Rating | 10A for 10secs, 5A continuous. |

3.7.2 CONFIGURABLE OUTPUTS C,D,E & F (E & F 4520 ONLY)


| | |
|------------|--|
| Type | Fully configurable, supplied from DC supply terminal 2. |
| Rating | 2A continuous |
| Protection | Protected against over current & over temperature. Built in load dump feature. |

3.8 COMMUNICATION PORTS

| | |
|----------|--|
| USB Port | USB2.0 Device for connection to PC running DSE configuration suite only Max distance 6m (yards) |
| CAN Port | Engine CAN Port Standard implementation of 'Slow mode', up to 250K bits/s Non-Isolated. Internal Termination provided (120Ω) Max distance 40m (133 feet) <div style="border: 1px solid black; padding: 5px; margin-top: 10px;"> ▲NOTE: For additional length, the DSE124 CAN Extender is available. Please refer to DSE Publication: 057-116 DSE124 Operator Manual for more information. </div> |

3.9 COMMUNICATION PORT USAGE

3.9.1 CAN INTERFACE



Modules are fitted with the CAN interface as standard and are capable of receiving engine data from engine CAN controllers compliant with the CAN standard.

CAN enabled engine controllers monitor the engine's operating parameters such as engine speed, oil pressure, engine temperature (among others) in order to closely monitor and control the engine. The industry standard communications interface (CAN) transports data gathered by the engine controller interface. This allows generator controllers to access these engine parameters with no physical connection to the sensor device.

▲NOTE: For further details for connections to CAN enabled engines and the functions available with each engine type, refer to DSE Publication: Part No. 057-004 DSE Electronic Engines and DSE Wiring.

3.11 DIMENSIONS AND MOUNTING

3.11.1 DIMENSIONS

140.0mm x 113mm x 43mm (5.5" x 4.4" x 1.7")

3.11.2 PANEL CUTOUT

118mm x 92mm (4.6" x 3.6")


3.11.3 WEIGHT

0.16kg (0.35lb)

3.11.4 FIXING CLIP

The module is held into the panel fascia using the supplied fixing clips.


- Withdraw the fixing clip screw (turn anticlockwise) until only the pointed end is protruding from the clip.
- Insert the three 'prongs' of the fixing clip into the slots in the side of the module case.
- Pull the fixing clip backwards (towards the back of the module) ensuring all three prongs of the clip are inside their allotted slots.
- Turn the fixing clip screws clockwise until they make contact with the panel fascia.
- Turn the screws a little more to secure the module into the panel fascia. Care should be taken not to over tighten the fixing clip screws.



NOTE: In conditions of excessive vibration, mount the module on suitable anti-vibration mountings.

3.11.5 SILICON SEALING GASKET

The supplied silicon gasket provides improved sealing between module and the panel fascia.
The gasket is fitted to the module before installation into the panel fascia.
Take care to ensure the gasket is correctly fitted to the module to maintain the integrity of the seal.



3.12 APPLICABLE STANDARDS

| | |
|--|--|
| BS 4884-1 | This document conforms to BS4884-1 1992 Specification for presentation of essential information. |
| BS 4884-2 | This document conforms to BS4884-2 1993 Guide to content |
| BS 4884-3 | This document conforms to BS4884-3 1993 Guide to presentation |
| BS EN 60068-2-1 (Minimum temperature) | -30°C (-22°F) |
| BS EN 60068-2-2 (Maximum temperature) | +70°C (158°F) |
| BS EN 60950 | Safety of information technology equipment, including electrical business equipment |
| BS EN 61000-6-2 | EMC Generic Immunity Standard (Industrial) |
| BS EN 61000-6-4 | EMC Generic Emission Standard (Industrial) |
| BS EN 60529 (Degrees of protection provided by enclosures) | IP65 (front of module when installed into the control panel with the supplied sealing gasket) IP42 (front of module when installed into the control panel WITHOUT being sealed to the panel) |
| UL508 NEMA rating (Approximate) | 12 (Front of module when installed into the control panel with the supplied sealing gasket). 2 (Front of module when installed into the control panel WITHOUT being sealed to the panel) |
| IEEE C37.2 (Standard Electrical Power System Device Function Numbers and Contact Designations) | <p>Under the scope of IEEE 37.2, <i>function numbers can also be used to represent functions in microprocessor devices and software programs.</i> The controller is device number 11L-8000 (Multifunction device protecting Line (generator) –module).</p> <p>As the module is configurable by the generator OEM, the functions covered by the module will vary. Under the module's factory configuration, the device numbers included within the module are :</p> <ul style="list-style-type: none"> 2 – Time delay starting or closing relay 6 – Starting circuit breaker 30 – annunciator relay 42 – Running circuit breaker 54 – turning gear engaging device 62 – time delay stopping or opening relay 63 – pressure switch 74– alarm relay 81 – frequency relay 86 – lockout relay |

3.12.1 ENCLOSURE CLASSIFICATIONS

IP CLASSIFICATIONS

The modules specification under **BS EN 60529** Degrees of protection provided by enclosures

IP65 (Front of module when module is installed into the control panel with the optional sealing gasket).

IP42 (front of module when module is installed into the control panel WITHOUT being sealed to the panel)

| First Digit | Second Digit |
|--|--|
| Protection against contact and ingress of solid objects | Protection against ingress of water |
| 0 No protection | 0 No protection |
| 1 Protected against ingress solid objects with a diameter of more than 50 mm. No protection against deliberate access, e.g. with a hand, but large surfaces of the body are prevented from approach. | 1 Protection against dripping water falling vertically. No harmful effect must be produced (vertically falling drops). |
| 2 Protected against penetration by solid objects with a diameter of more than 12 mm. Fingers or similar objects prevented from approach. | 2 Protection against dripping water falling vertically. There must be no harmful effect when the equipment (enclosure) is tilted at an angle up to 15° from its normal position (drops falling at an angle). |
| 3 Protected against ingress of solid objects with a diameter of more than 2.5 mm. Tools, wires etc. with a thickness of more than 2.5 mm are prevented from approach. | 3 Protection against water falling at any angle up to 60° from the vertical. There must be no harmful effect (spray water). |
| 4 Protected against ingress of solid objects with a diameter of more than 1 mm. Tools, wires etc. with a thickness of more than 1 mm are prevented from approach. | 4 Protection against water splashed against the equipment (enclosure) from any direction. There must be no harmful effect (splashing water). |
| 5 Protected against harmful dust deposits. Ingress of dust is not totally prevented but the dust must not enter in sufficient quantity to interface with satisfactory operation of the equipment. Complete protection against contact. | 5 Protection against water projected from a nozzle against the equipment (enclosure) from any direction. There must be no harmful effect (water jet). |
| 6 Protection against ingress of dust (dust tight). Complete protection against contact. | 6 Protection against heavy seas or powerful water jets. Water must not enter the equipment (enclosure) in harmful quantities (splashing over). |

3.12.2 NEMA CLASSIFICATIONS

The modules NEMA Rating (Approximate)

12 (Front of module when module is installed into the control panel with the optional sealing gasket).

2 (front of module when module is installed into the control panel WITHOUT being sealed to the panel)



NOTE: There is no direct equivalence between IP / NEMA ratings. IP figures shown are approximate only.

| | |
|-----------------------|--|
| 1 IP30 | Provides a degree of protection against contact with the enclosure equipment and against a limited amount of falling dirt. |
| 2 IP31 | Provides a degree of protection against limited amounts of falling water and dirt. |
| 3 IP64 | Provides a degree of protection against windblown dust, rain and sleet; undamaged by the formation of ice on the enclosure. |
| 3R IP32 | Provides a degree of protection against rain and sleet;; undamaged by the formation of ice on the enclosure. |
| 4 (X) IP66 | Provides a degree of protection against splashing water, windblown dust and rain, hose directed water; undamaged by the formation of ice on the enclosure. (Resist corrosion). |
| 12/12K IP65 | Provides a degree of protection against dust, falling dirt and dripping non corrosive liquids. |
| 13 IP65 | Provides a degree of protection against dust and spraying of water, oil and non corrosive coolants. |


4 INSTALLATION

The module is designed to be mounted on the panel fascia. For dimension and mounting details, see the section entitled *Specification, Dimension and mounting* elsewhere in this document.

4.1 TERMINAL DESCRIPTION

To aid user connection, icons are used on the rear of the module to help identify terminal functions. An example of this is shown below.

NOTE: Availability of some terminals depends upon module version. Full details are given in the section entitled *Terminal Description* elsewhere in this manual.



4.1.1 DC SUPPLY, FUEL AND START OUTPUTS, OUTPUTS C,D,E & F

| PIN No | DESCRIPTION | CABLE SIZE | NOTES |
|--------|----------------------------------|-------------------------------|--|
| 1 | DC Plant Supply Input (Negative) | 2.5mm ² AWG 13 | |
| 2 | DC Plant Supply Input (Positive) | 2.5 mm ² AWG 13 | (Recommended Maximum Fuse 15A anti-surge) Supplies the module (2A anti-surge requirement) and Output relays E,F,G & H |
| 3 | Output relay A (FUEL) | 2.5mm ² AWG 13 | Plant Supply Positive from terminal 3. 15 Amp rated. Fixed as FUEL relay if electronic engine is not configured. |
| 4 | Output relay B (START) | 2.5mm ² AWG 13 | Plant Supply Positive from terminal 3. 15 Amp rated. Fixed as START relay if electronic engine is not configured. |
| 5 | Charge fail / excite | 2.5mm ² AWG 13 | Do not connect to ground (battery negative). If charge alternator is not fitted, leave this terminal disconnected. |
| 6 | Output relay C | 1.0mm ² AWG 18 | Plant Supply Positive from terminal 2. 2 Amp rated. |
| 7 | Output relay D | 1.0mm ² AWG 18 | Plant Supply Positive from terminal 2. 2 Amp rated. |
| 8 | Output relay E | 1.0mm ² AWG 18 | Plant Supply Positive from terminal 2. 2 Amp rated. |
| 9 | Output relay F | 1.0mm ² AWG 18 | Plant Supply Positive.from terminal 2. 2 Amp rated. |



NOTE: Output relays E & F (terminals 8 & 9) are not fitted to DSE4510 controller.



NOTE: When the module is configured for operation with an electronic engine, FUEL and START output requirements may be different. Refer to Publication: Part No. 057-004. Electronic Engines and DSE Wiring.

4.1.2 ANALOGUE SENSOR

| PIN No | DESCRIPTION | CABLE SIZE | NOTES |
|--------|---------------------------|------------------------------|--|
| 10 | Sensor Common Return | 0.5mm ² AWG 20 | Return feed for sensors* |
| 11 | Oil Pressure Input | 0.5mm ² AWG 20 | Connect to Oil pressure sensor |
| 12 | Coolant Temperature Input | 0.5mm ² AWG 20 | Connect to Coolant Temperature sensor |
| 13 | Flexible sensor | 0.5mm ² AWG 20 | Connect to additional sensor (user configurable) |



NOTE: It is VERY important that terminal 10 (sensor common) is soundly connected to an earth point on the ENGINE BLOCK, not within the control panel, and must be a sound electrical connection to the sensor bodies. This connection MUST NOT be used to provide an earth connection for other terminals or devices. The simplest way to achieve this is to run a SEPARATE earth connection from the system earth star point, to terminal 15 directly, and not use this earth for other connections.

4.1.3 CONFIGURABLE DIGITAL INPUTS

| PIN No | DESCRIPTION | CABLE SIZE | NOTES |
|--------|------------------------------|------------------------------|--------------------|
| 14 | Configurable digital input A | 0.5mm ² AWG 20 | Switch to negative |
| 15 | Configurable digital input B | 0.5mm ² AWG 20 | Switch to negative |
| 16 | Configurable digital input C | 0.5mm ² AWG 20 | Switch to negative |
| 17 | Configurable digital input D | 0.5mm ² AWG 20 | Switch to negative |



NOTE: See the software manual for full range of configurable inputs available.

4.1.4 CAN

| PIN No | DESCRIPTION | CABLE SIZE | NOTES |
|--------|-----------------|------------------------------|----------------------------------|
| 18 | CAN port H | 0.5mm ² AWG 20 | Use only 120Ω CAN approved cable |
| 19 | CAN port L | 0.5mm ² AWG 20 | Use only 120Ω CAN approved cable |
| 20 | Can port common | 0.5mm ² AWG 20 | Use only 120Ω CAN approved cable |



NOTE: Screened 120Ω impedance cable specified for use with CAN must be used for the CAN link. DSE stock and supply Belden cable 9841 which is a high quality 120Ω impedance cable suitable for CAN use (DSE part number 016-030)

4.1.5 GENERATOR / MAINS VOLTAGE SENSING

| PIN No | DESCRIPTION | CABLE SIZE | NOTES |
|--------|-------------------------------------|------------------------------|--|
| 21 | Generator L1 (U) voltage monitoring | 1.0mm ² AWG 18 | Connect to generator L1 (U) output (AC) (Recommend 2A fuse) |
| 22 | Generator L2 (V) voltage monitoring | 1.0mm ² AWG 18 | Connect to generator L2 (V) output (AC) (Recommend 2A fuse) |
| 23 | Generator L3 (W) voltage monitoring | 1.0mm ² AWG 18 | Connect to generator L3 (W) output (AC) (Recommend 2A fuse) |
| 24 | Generator Neutral (N) input | 1.0mm ² AWG 18 | Connect to generator Neutral terminal (AC) |
| 25 | Mains L1 (R) voltage monitoring | 1.0mm ² AWG 18 | Connect to Mains L1 (R) output (AC) (Recommend 2A fuse) |
| 26 | Mains L2 (S) voltage monitoring | 1.0mm ² AWG 18 | Connect to Mains L2 (S) output (AC) (Recommend 2A fuse) |
| 27 | Mains L3 (T) voltage monitoring | 1.0mm ² AWG 18 | Connect to Mains L3 (T) output (AC) (Recommend 2A fuse) |
| 28 | Mains Neutral (N) input | 1.0mm ² AWG 18 | Connect to Mains Neutral terminal (AC) |



NOTE: The above table describes connections to a three phase, four wire alternator. For alternative wiring topologies, please see the ALTERNATIVE AC TOPOLOGIES section of this manual.



NOTE: Terminals 25 – 28 not fitted to DSE4510

4.1.6 GENERATOR CURRENT TRANSFORMERS

NOTE: Current Sensing (terminals 29-32) is not fitted to 4510-01 / 4520-01.

WARNING! Do not disconnect this plug when the CTs are carrying current. Disconnection will open circuit the secondary of the C.T.'s and dangerous voltages may then develop. Always ensure the CTs are not carrying current and the CTs are short circuit connected before making or breaking connections to the module.

NOTE: The module has a burden of 0.5VA on the CT. Ensure the CT is rated for the burden of the controller, the cable length being used and any other equipment sharing the CT. If in doubt, consult your CT supplier.

| PIN No | DESCRIPTION | CABLE SIZE | NOTES |
|--------|-------------------------|------------------------------|---|
| 29 | CT Secondary for Gen L1 | 2.5mm ² AWG 13 | Connect to s1 secondary of L1 monitoring CT |
| 30 | CT Secondary for Gen L2 | 2.5mm ² AWG 13 | Connect to s1 secondary of L2 monitoring CT |
| 31 | CT Secondary for Gen L3 | 2.5mm ² AWG 13 | Connect to s1 secondary of L3 monitoring CT |
| 32 | CT Common | 2.5mm ² AWG 13 | |


CT CONNECTIONS

p1, \bar{k} or K is the primary of the CT that 'points' towards the GENERATOR



p2, \bar{l} or L is the primary of the CT that 'points' towards the LOAD

s1 is the secondary of the CT that connects to the DSE Module's input for the CT measuring (I1,I2,I3)

s2 is the secondary of the CT that should be commoned with the s2 connections of all the other CTs and connected to the CT common terminal of the module.



4.1.7 PC CONFIGURATION INTERFACE CONNECTOR

| | DESCRIPTION | CABLE SIZE | NOTES |
|---|---|------------------------------|--|
|  | Socket for connection to PC with DSE Configuration Suite Software and remote communication. | 0.5mm ² AWG 20 | This is a standard USB type A to type B connector.  |

▲ NOTE: The USB connection cable between the PC and the module must not be extended beyond 5m (yards). For distances over 5m, it is possible to use a third party USB extender. Typically, they extend USB up to 50m (yards). The supply and support of this type of equipment is outside the scope of Deep Sea Electronics PLC.

! CAUTION!: Care must be taken not to overload the PC's USB system by connecting more than the recommended number of USB devices to the PC. For further information, consult your PC supplier.

4.2 TYPICAL WIRING DIAGRAMS


As every system has different requirements, these diagrams show only a TYPICAL system and do not intend to show a complete system.

Genset manufacturers and panel builders may use these diagrams as a starting point; however, you are referred to the completed system diagram provided by your system manufacturer for complete wiring detail.

Further wiring suggestions are available in the following DSE publications, available at www.deepseapl.com to website members.


| DSE PART | DESCRIPTION |
|-----------------|-----------------------------------|
| 056-022 | Breaker Control (Training guide) |
| 057-004 | Electronic Engines and DSE Wiring |

4.2.1 DSE4510 AUTOSTART MODULE



NOTE: Terminals 29-32 not fitted on 4510-01

4.2.2 DSE4520 AUTO MAINS FAILURE MODULE



BATTERY NEGATIVE MUST BE GROUNDED

TERMINALS SUITABLE FOR 22-16 AWG (0.6mm – 1.3mm) FIELD WIRING
TIGHTENING TORQUE = 0.8Nm (7lb-in)

NOTE 1. THESE GROUND CONNECTIONS MUST BE ON THE ENGINE BLOCK, AND MUST BE TO THE SENDER BODIES.

NOTE 3. IT IS RECOMMENDED THAT THE GENERATOR AND MAINS SWITCHING DEVICES ARE MECHANICALLY AND ELECTRICALLY INTERLOCKED.


†NOTE 2. 120 R TERMINATING RESISTOR MAY BE REQUIRED EXTERNALLY, SEE ENGINE MANUFACTURERS LITERATURE.

* NOTE 4. MAINS BREAKER CLOSED OUTPUT SHOULD BE CONFIGURED FOR DE-ENERGISE CLOSE MAINS, AND USE THE NORMALLY CLOSED CONTACTS OF MBCR

NOTE: Terminals 29-32 not fitted on 4520-01

















5 MODULE DISPLAY

The module's display contains





5.1 INSTRUMENTATION ICONS

When displaying instrumentation a small icon is displayed in the instrumentation area to indicate what value is currently being displayed.

| Icon | Description |
|---|--|
|  | Generator voltage and generator frequency |
|  | Mains voltages and mains frequency |
|  | Current |
|  | Engine speed |
|  | Engine running hours |
|  | Battery voltage |
|  | Oil pressure |
|  | Coolant temperature |
|  | Flexible sensor |
|  | Appears when the event log is being displayed |
|  | Current time held in the unit |
|  | The current value of the scheduler run time and duration |
|  | ECU diagnostic trouble codes |
|  | Oil Filter maintenance timers |
|  | Air Filter maintenance timers |
|  | Fuel Filter maintenance timers |










5.2 ACTIVE CONFIGURATION

An icon on the display shows the currently active configuration within the controller.

| Icon | Details |
|---|---|
|  | Appears when the main configuration is selected. |
|  | Appears when the alternative configuration is selected. |





5.3 MODE ICON

An icon is displayed in the mode icon area of the display to indicate what mode the unit is currently in.

| Icon | Details |
|---|---|
|  | Appears when the engine is at rest and the unit is in stop mode. |
|  | Appears when the engine is at rest and the unit is in auto mode. |
|  | Appears when the engine is at rest and the unit is in test mode. |
|  | Appears when the engine is at rest and the unit is in armed mode. |
|  | Appears when a timer is active, for example cranking time, crank rest etc. |
|  | Appears when the engine is running, and all timers have expired, either on or off load. The animation speed is reduced when running in idle mode. |
|  | Appears when the unit is in the front panel editor. |
|  | Appears when a USB connection is made to the controller. |
|  | Appears if either the configuration file or engine file becomes corrupted. |

5.4 AUTO RUN ICON


When running in Auto Mode, an icon is shown on the home screen to identify why the engine is being run.

| Icon | Auto run reason |
|---|--------------------|
|  | Remote start input |
|  | Low battery run |
|  | Scheduled run |
|  | Mains failure |


5.5 BACKLIGHT

The LCD backlight is on if the unit has sufficient voltage while the unit is turned on, unless the unit is cranking for which the backlight is turned off.

5.6 FAULT ICONS

| ICON | DESCRIPTION | |
|------|--|---|
| | AUXILIARY INPUTS | Auxiliary inputs can be user configured and will display the message as written by the user. |
| | FAIL TO START | The engine has not fired after the preset number of start attempts |
| | FAIL TO STOP | <p>The module has detected a condition that indicates that the engine is running when it has been instructed to stop.</p> <p> NOTE: 'Fail to Stop' could indicate a faulty oil pressure sensor - If engine is at rest check oil sensor wiring and configuration.</p> |
| | LOW OIL PRESSURE | The module detects that the engine oil pressure has fallen below the low oil pressure pre-alarm setting level after the Safety On timer has expired. |
| | ENGINE HIGH TEMPERATURE | The module detects that the engine coolant temperature has exceeded the high engine temperature pre-alarm setting level after the Safety On timer has expired. |
| | UNDERSPEED | The engine speed has fallen below the underspeed pre alarm setting |
| | OVERSPEED | The engine speed has risen above the overspeed pre alarm setting |
| | CHARGE FAILURE | The auxiliary charge alternator voltage is low as measured from the W/L terminal. |
| | LOW FUEL LEVEL | The level detected by the fuel level sensor is below the low fuel level setting. |
| | BATTERY UNDER VOLTAGE / BATTERY OVER VOLTAGE | The DC supply has fallen below or risen above the low/high volts setting level. |
| | GENERATOR UNDER VOLTAGE | The generator output voltage has fallen below the pre-set pre-alarm setting after the Safety On timer has expired. |
| | GENERATOR OVER VOLTAGE | The generator output voltage has risen above the pre-set pre-alarm setting. |
| | GENERATOR UNDER FREQUENCY | The generator output frequency has fallen below the pre-set pre-alarm setting after the Safety On timer has expired. |
| | GENERATOR OVER FREQUENCY | The generator output frequency has risen above the pre-set pre-alarm setting. |
| | CAN ECU WARNING CAN ECU SHUTDOWN | The engine ECU has detected an alarm – CHECK ENGINE LIGHT Contact Engine Manufacturer for support. |
| | CAN DATA FAIL | The module is configured for CAN operation and does not detect data on the engine Can data link. |
| | EMERGENCY STOP | The emergency stop button has been depressed. This failsafe (normally closed to emergency stop) input and will immediately stop the set should the signal be removed. |
| | OIL SENDER OPEN CIRCUIT | Oil pressure sensor has been detected as being open circuit. |
| | FLEXIBLE SENSOR | The flexible sensor shutdown alarm has been triggered. |
| | OVERCURRENT | The current has risen above the set limit trip. |
| | OIL FILTER MAINTENANCE ALARM | Maintenance due for oil filter. |
| | AIR FILTER MAINTENANCE ALARM | Maintenance due for air filter |
| | FUEL FILTER MAINTENANCE ALARM | Maintenance due for fuel filter. |


6 DESCRIPTION OF CONTROLS



6.1 QUICKSTART GUIDE

This section provides a quick start guide to the module's operation.

6.1.1 STARTING THE ENGINE





NOTE: For further details, see the section entitled 'OPERATION' elsewhere in this manual.

6.1.2 STOPPING THE ENGINE




NOTE: For further details, see the section entitled 'OPERATION' elsewhere in this manual.

6.2 VIEWING THE INSTRUMENT PAGES


It is possible to scroll to display the different pages of information by repeatedly operating the page buttons.  (previous) and  (next).

Example:

When viewing the Home page, press the  (down) button to change to the Generator instrument page.



Once selected the page will remain on the LCD display until the user selects a different page, or after an extended period of inactivity (*Page Delay Timer*), the module will revert to the status display.

The *Page Delay Timer* is configurable using the DSE Configuration Suite Software or by using the Front Panel Editor.



NOTE: For further details of module configuration, see DSE Publication: 057-172. DSE4510 / DSE4520 Software Manual.









6.2.1 MENU

Alternatively you can enter the menu by holding down both  (up) and  (down) buttons simultaneously.
The menu is then displayed.



Press the  (up) or  (down) buttons to select the required icon, then press  (✓) to enter the page.

If an alarm becomes active while viewing the status page, the display shows the Alarms page to draw the operator's attention to the alarm condition.

| Icon | Description |
|---|---|
|  | Home |
|  | Generator instrumentation |
|  | Mains instrumentation |
|  | Load instrumentation (4510-02 / 4520-02 only) |
|  | Engine instrumentation |
|  | Info |
|  | Engine DTCs (Diagnostic Trouble Codes) |
|  | Event |

6.2.2 HOME

This is the page that is displayed when no other page has been selected, and the page that is automatically displayed after a period of inactivity (*Page Delay Timer*) of the module control buttons.

6.2.3 GENERATOR

Contains electrical values of the generator (alternator), measured or derived from the module's voltage and current inputs.

- Generator Voltage (ph-N)
- Generator Voltage (ph-ph)
- Generator Frequency
- Generator Current *
- Generator Total Load (kW) *
- Generator Load (kW) *
- Generator Total Load (kVA) *
- Generator Power Factor *
- Generator Power Factor Average *
- Generator Load (kWh, kVAh, kVArh) *



NOTE: * Not applicable to 4510-01 & 4520-01

6.2.4 MAINS (DSE4520 ONLY)

- Mains Voltage (ph-N)
- Mains Voltage (ph-ph)
- Mains Frequency

6.2.5 ENGINE

Contains instrumentation gathered about the engine itself, some of which may be obtained using the CAN or other electronic engine link.

- Engine Speed
- Oil Pressure
- Coolant Temperature
- Engine Battery Volts
- Engine Run Time
- Engine Maintenance Due – Oil (If configured)
- Engine Maintenance Due – Air (If configured)
- Engine Maintenance Due – Fuel (If configured)









6.2.6 INFO

Contains information about the controller.

- Model number
- USB identification number
- Configured Engine Type
- Module's date and time
- Scheduler setting

6.2.7 ENGINE DTC

This page contains any active *Diagnostic Trouble Codes* that the engine ECU is currently generating. These are alarm conditions detected by the engine ECU and displayed by the DSE controller.









| Icon | DTC meaning |
|---|----------------------------------|
|  | Check engine (unspecified) fault |
|  | Overspeed |
|  | Underspeed |
|  | Oil pressure low |
|  | Coolant temperature high |
|  | Charge Alt high or low |
|  | Low fuel |
|  | Battery high or low |

6.2.8 EVENT


Contains a list of the last 5 events.


7 OPERATION

7.1 CONTROL PUSH-BUTTONS

| | |
|--|--|
| <p>Stop / Reset This button places the module into its Stop/Reset  mode. will clear any alarm conditions for which the triggering criteria have been removed. If the engine is running and the module is in Stop mode, the module will automatically instruct the changeover device to unload the generator ('Close Generator' becomes inactive (if used)). The fuel supply de-energises and the engine comes to a standstill. Should a remote start signal be present while operating in this mode, a remote start will <u>not</u> occur.</p> |  |
| <p>Auto This button places the module into its 'Automatic' mode. This mode allows the module to control the function of the generator automatically. The module will monitor the <i>remote start</i> input and mains supply status and once a start request is made, the set will be automatically started and placed on load. Upon removal of the starting signal, the module will automatically transfer the load from the generator and shut the set down observing the <i>stop delay</i> timer and <i>cooling</i> timer as necessary. The module will then await the next start event. <i>For further details, please see the more detailed description of 'Auto operation' elsewhere in this manual.</i></p> |  |
| <p>Start This button is only active in STOP/RESET mode. Pressing this button in manual or test mode will start the engine and run off load (manual) or on load (test). Pressing this button in STOP/RESET  mode will turn on the CAN engine ECU (when correctly configured and fitted to a compatible engine ECU)</p> |  |
| <div style="border: 1px solid black; padding: 5px;">  NOTE: Different modes of operation are possible - Please refer to your configuration source for details. </div> | |
| <p>Menu navigation Used for navigating the instrumentation, event log and configuration screens. For further details, please see the more detailed description of these items elsewhere in this manual.</p> |   |

7.2 STOP MODE


STOP mode is activated by pressing the  button.



In STOP  mode, the module will remove the generator from load (if necessary) before stopping the engine if it is already running.


If the engine does not stop when requested, the FAIL TO STOP alarm is activated (subject to the setting of the *Fail to Stop* timer). To detect the engine at rest the following must occur :

- Engine speed is zero as CANbus ECU (Electronic Engine).
- Generator frequency must be zero.
- Oil pressure switch must be closed to indicate low oil pressure.

When the engine has stopped, it is possible to send configuration files to the module from DSE Configuration Suite PC software and to enter the Front Panel Editor to change parameters.

Any latched alarms that have been cleared will be reset when STOP  mode is entered.

The engine will not be started when in STOP  mode. If remote start signals are given, the input is ignored until AUTO  mode is entered.

When configured to do so, when left in STOP  mode for the time set for 'Power Save Mode' with no presses of the fascia buttons, the module enters Power Save Mode. To 'wake' the module, press any fascia control button or a Remote Start input. The same is true for Deep Sleep Mode.


Power Save & Deep Sleep Modes in the DSE Configuration Suite Software

| | |
|------------------------|-------------------------------------|
| Power Save Mode Enable | <input checked="" type="checkbox"/> |
| Deep Sleep Mode Enable | <input checked="" type="checkbox"/> |

 **NOTE: For further details, see DSE Publication: 057-172 DSE4510 / 4520 Software Manual.**



7.2.1 ECU OVERRIDE

 **NOTE:** ECU Override function is only applicable when the controller is configured for a CAN engine and *Protected Start* is enabled.

 **NOTE:** Depending upon system design, the ECU may be powered or unpowered when the module is in STOP mode. ECU override is only applicable if the ECU is unpowered when in STOP mode.

When the ECU is powered down (normal operation in STOP mode), it is not possible to read the diagnostic trouble codes or instrumentation. Additionally, it is not possible to use the engine manufacturers' configuration tools.



As the ECU is usually unpowered when the engine is not running, it must be turned on manually as follows :

- Select STOP  mode on the DSE controller.
- Press and hold the START  button to power the ECU. As the controller is in STOP mode, the engine will not be started.

This is also useful if the engine manufacturer's tools need to be connected to the engine, for instance to configure the engine as the ECU needs to be powered up to perform this operation.

7.3 AUTOMATIC MODE

NOTE: If a digital input configured to external *panel lock* is active, changing module modes will not be possible. Viewing the instruments and event logs is NOT affected by panel lock.

Activate auto mode by pressing the  pushbutton. The  icon is displayed to indicate Auto Mode operations if no alarms are present.

Auto mode will allow the generator to operate fully automatically, starting and stopping as required with no user intervention.

7.3.1 WAITING IN AUTO MODE

If a starting request is made, the starting sequence will begin. Starting requests can be from the following sources :

- Activation of an auxiliary input that has been configured to *remote start*
- Activation of the inbuilt exercise scheduler.
- Mains failure (DSE4520 only).


7.3.2 STARTING SEQUENCE

To allow for 'false' start requests, the *start delay* timer begins.


Should all start requests be removed during the *start delay* timer, the unit will return to a stand-by state.

If a start request is still present at the end of the *start delay* timer, the fuel relay is energised and the engine will be cranked.

NOTE: If the unit has been configured for CAN, compatible ECU's will receive the start command via CAN and transmit the engine speed to the DSE controller.

If the engine fails to fire during this cranking attempt then the starter motor is disengaged for the *crank rest* duration after which the next start attempt is made. Should this sequence continue beyond the set number of attempts, the start sequence will be terminated and the display shows  **Fail to Start**.

7.3.3 ENGINE RUNNING

Once the engine is running and all starting timers have expired, the animated  icon is displayed.

The generator will be placed on load if configured to do so.

NOTE: The load transfer signal remains inactive until the Oil Pressure has risen. This prevents excessive wear on the engine.

If all start requests are removed, the *stopping sequence* will begin.

7.3.4 STOPPING SEQUENCE

The *return delay* timer operates to ensure that the starting request has been permanently removed and isn't just a short term removal. Should another start request be made during the cooling down period, the set will return on load.


If there are no starting requests at the end of the *return delay* timer, the load is removed from the generator to the mains supply and the *cooling* timer is initiated.

The *cooling* timer allows the set to run off load and cool sufficiently before being stopped. This is particularly important where turbo chargers are fitted to the engine.

After the *cooling* timer has expired, the set is stopped.



7.4 MANUAL MODE

NOTE: If a digital input configured to panel lock is active, changing module modes will not be possible. Viewing the instruments and event logs is NOT affected by panel lock.

Manual mode allows the operator to start and stop the set manually, and if required change the state of the load switching devices. . Module mode is active when the  button is pressed.

7.4.1 WAITING IN MANUAL MODE

To begin the starting sequence, press the  button. If '*protected start*' is disabled, the start sequence begins immediately.

If 'Protected Start' is enabled, the  icon is displayed to indicate Manual mode and the manual LED flashes. The  button must be pressed once more to begin the start sequence.

Protected Start Mode



Protected Start Mode setting in the DSE Configuration Suite Software

NOTE: For further details, see the Publication: 057-172 DSE4510/4520 Software Manual.

7.4.2 STARTING SEQUENCE

NOTE: There is no *start delay* in this mode of operation.

The fuel relay is energised and the engine is cranked.

NOTE: If the unit has been configured for CAN, compatible ECU's will receive the start command via CAN.

If the engine fails to fire during this cranking attempt then the starter motor is disengaged for the *crank rest* duration after which the next start attempt is made. Should this sequence continue beyond the set number of attempts, the start sequence will be terminated and the display shows **Fail to Start**.

When the engine fires, the starter motor is disengaged. Speed detection is factory configured to be derived from the main alternator output frequency.

Additionally, rising oil pressure can be used disconnect the starter motor (but cannot detect under speed or over speed).

After the starter motor has disengaged, the *Safety On* timer activates, allowing Oil Pressure, High Engine Temperature, Under-speed, Charge Fail and any delayed Auxiliary fault inputs to stabilise without triggering the fault.



7.4.3 ENGINE RUNNING

In manual mode, the load is not transferred to the generator unless a 'loading request' is made. A loading request can come from a number of sources.

- Mains supply out of limits (DSE4520 only)
- Activation of an auxiliary input that has been configured to *remote start on load*
- Activation of the inbuilt exercise scheduler if configured for 'on load' runs.

 **NOTE: The load transfer signal remains inactive until the Oil Pressure has risen. This prevents excessive wear on the engine.**



Once the load has been transferred to the generator, it will not be automatically transferred back to the mains supply. To manually transfer the load back to the mains either:

- Press the *auto mode*  button to return to automatic mode. The set will observe all auto mode start requests and stopping timers before beginning the *Auto mode stopping sequence*.
- Press the *stop button* 
- De-activation of an auxiliary input that has been configured to *remote start on load*

For further details of breaker control, see the section entitled "controls and indications" elsewhere in this manual.

7.4.4 STOPPING SEQUENCE

In manual mode the set will continue to run until either :

- The *stop button*  is pressed – The set will immediately stop
- The *auto button*  is pressed. The set will observe all auto mode start requests and stopping timers before beginning the *Auto mode stopping sequence*.

7.5 MAINTENANCE ALARM

Depending upon module configuration one or more levels of maintenance alarm may occur based upon a configurable schedule.

Example 1

Screen capture from DSE Configuration Suite Software showing the configuration of Maintenance Alarm for Oil, Air or Fuel.

When activated, the maintenance alarm can be either a **warning** (set continues to run) or **shutdown** (running the set is not possible). Resetting the maintenance alarm is normally actioned by the site service engineer after performing the required maintenance. The method of reset is either by:

- Activating an input that has been configured to maintenance x reset, where x is the number of the maintenance alarm (Oil, Air or Fuel).
- Pressing the maintenance reset button in the DSE Configuration Suite, Maintenance section.

The screenshot shows the 'Maintenance Alarm' configuration interface. It contains three sections: 'Maintenance Alarm Oil', 'Maintenance Alarm Air', and 'Maintenance Alarm Fuel'. Each section has an 'Enable' checkbox (checked), an 'Action' dropdown menu (set to 'Warning'), and an 'Engine run hours' slider (set to 10 hrs).

Example 2

Screen capture from DSE Configuration Suite Software showing the configuration of a digital input for Maintenance Rest Alarm Oil.

The screenshot shows the 'Digital Input A' configuration interface. It includes a 'Function' dropdown menu (set to 'Maintenance Reset Alarm Oil'), a 'Polarity' dropdown menu (set to 'Close to Activate'), an 'Action' dropdown menu, an 'Arming' dropdown menu, and an 'Activation Delay' slider (set to 0s).

Example 3

Screen capture from DSE Configuration Suite Software showing the Maintenance Alarm Reset 'button' in the DSE Configuration Suite SCADA | MAINTENANCE section.

The screenshot shows the 'Maintenance Alarm - Oil' screen. It displays 'Running Time Until Next Maintenance' as 10:00. Below this is a 'Reset' button. At the bottom, there is a message: 'Press reset to schedule next maintenance, based upon module's maintenance configuration.'

8 SCHEDULER


The controller contains an inbuilt exercise run scheduler, capable of automatically starting and stopping the set. Scheduled run may be on load or off load depending upon module configuration.

Example





Screen capture from DSE Configuration Suite Software showing the configuration of the Exercise Scheduler.

In this example the set will start at 09:00 on Monday and run for 5 hours.

8.1.1 STOP MODE

- Scheduled runs will not occur when the module is in STOP/RESET  mode.


8.1.2 AUTO MODE

- Scheduled runs will operate ONLY if the module is in AUTO  mode with no Shutdown or Electrical Trip alarm present.
- If the module is in STOP  mode when a scheduled run begins, the engine will not be started. However, if the module is moved into AUTO  mode during a scheduled run, the engine will be called to start.
- Depending upon configuration by the system designer, an external input can be used to inhibit a scheduled run.
- If the engine is running OFF LOAD in AUTO  mode and a scheduled run configured to 'On Load' begins, the set is placed ON LOAD for the duration of the Schedule.

9 FRONT PANEL CONFIGURATION



This configuration mode allows the operator limited customising of the way the module operates.

Use the module's navigation buttons to navigate the menu and make changes to the settings:





9.1 ACCESSING THE FRONT PANEL CONFIGURATION EDITOR


Ensure the engine is at rest and the module is in STOP mode by pressing the Stop/Reset  button.


Press the Stop/Reset  and Auto  buttons simultaneously.


If a module security PIN has been set, the PIN number request is then shown :



Press  (up) or  (down) buttons to adjust it to the correct value.


Press  (Start) when the first digit is correctly entered. The digit you have just entered will now show '#' for security.

Repeat this process for the other digits of the PIN number. You can press  (Stop) if you need to move back to adjust one of the previous digits.


When  is pressed after editing the final PIN digit, the PIN is checked for validity. If the number is not correct, you must re-enter the PIN.



If the PIN has been successfully entered (or the module PIN has not been enabled), the editor is displayed :





 **NOTE:** The PIN number is not set by DSE when the module leaves the factory. If the module has a PIN code set, this has been affected by your generator supplier who should be contacted if you require the code. If the code has been 'lost' or 'forgotten', the module must be returned to the DSE factory to have the module's code removed. A charge will be made for this procedure.
NB - This procedure cannot be performed away from the DSE factory.

 **NOTE:** The PIN number is automatically reset when the editor is exited (manually or automatically) to ensure security.

To edit the parameter, press  (✓) to enter edit mode. The parameter begins to flash to indicate that you are editing the value.



Press  (up) or  (down) buttons to change the parameter to the required value.


Press  (✓) to save the value. The parameter ceases flashing to indicate that it has been saved.

To exit the editor at any time, press and hold the  (✓) button.

9.1.1 EDITING A PARAMETER

Enter the editor as described above.

Press  (up) or  (down) buttons to cycle to the section you wish to view/change.

Press the  button to select the next parameter you wish to view/change within the currently selected section.

 **NOTE: The editor automatically exits after 5 minutes of inactivity to ensure security.**

9.2 ADJUSTABLE PARAMETERS

CONFIGURATION PARAMETERS- MODULE (PAGE 1)

| | | | | | |
|-----|--------------------------|-----------------|-----|--------------------------------|-----------------|
| 101 | Contrast | 000 (%) | 111 | Display ph-ph | On (1), Off (0) |
| 102 | Fast Loading Enabled | On (1), Off (0) | 112 | Pin Number | 0000 |
| 103 | All Warnings Latched | On (1), Off (0) | 113 | Stop Button Cooldown | On (1), Off (0) |
| 104 | Lamp Test at Start-up | On (1), Off (0) | 114 | Use Module Oil Pressure | On (1), Off (0) |
| 105 | Power Save Mode Enable | On (1), Off (0) | 115 | Use Module Coolant Temperature | On (1), Off (0) |
| 106 | Deep Sleep Mode Enable | On (1), Off (0) | 116 | Use Module Engine Hours | On (1), Off (0) |
| 107 | Protected Start Enabled | On (1), Off (0) | 117 | Use Module RPM | On (1), Off (0) |
| 108 | Event Log Display Format | On (1), Off (0) | 118 | Use Module Chg Alt | On (1), Off (0) |
| 109 | Start Mode | 0 (Mode) | 119 | Disable TSC1 Speed Feed | On (1), Off (0) |
| 110 | DTC String Enable | On (1), Off (0) | | | |

CONFIGURATION PARAMETERS- APPLICATION (PAGE 2)





| | | | | | |
|-----|--------------------------|-----------------|-----|--------------------------|------------|
| 201 | Alternative Engine Speed | On (1), Off (0) | 203 | CAN ECU Data Fail Action | 0 (Action) |
| 202 | CAN ECU Data Fail Enable | On (1), Off (0) | 204 | CAN ECU Data Fail Delay | 0 s |

CONFIGURATION PARAMETERS – INPUTS (PAGE 3)

| | | |
|-----|--|-------------------------|
| 301 | Low Oil Pressure Enable | On (1), Off (0) |
| 302 | Low Oil Pressure Trip | 0% / 0.00 Bar / 0 Deg C |
| 303 | High Engine Temperature Trip | 00 Deg C / 00 Deg F |
| 304 | Digital Input A Source | 0 (Input Source) |
| 305 | Digital Input A Polarity | 0 (Polarity) |
| 306 | Digital Input A Action (If Source = User Configured) | 0 (Action) |
| 307 | Digital Input A Arming (If Source = User Configured) | 0 (Arming) |
| 308 | Digital Input A Activation Delay (If Source = User Configured) | 0:00 |
| 309 | Digital Input B Source | 0 (Input Source) |
| 310 | Digital Input B Polarity | 0 (Polarity) |
| 311 | Digital Input B Action (If Source = User Configured) | 0 (Action) |
| 312 | Digital Input B Arming (If Source = User Configured) | 0 (Arming) |
| 313 | Digital Input B Activation Delay (If Source = User Configured) | 0:00 |
| 314 | Digital Input C Source | 0 (Input Source) |
| 315 | Digital Input C Polarity | 0 (Polarity) |
| 316 | Digital Input C Action (If Source = User Configured) | 0 (Action) |
| 317 | Digital Input C Arming (If Source = User Configured) | 0 (Arming) |
| 318 | Digital Input C Activation Delay (If Source = User Configured) | 0:00 |
| 319 | Digital Input D Source | 0 (Input Source) |
| 320 | Digital Input D Polarity | 0 (Polarity) |
| 321 | Digital Input D Action (If Source = User Configured) | 0 (Action) |
| 322 | Digital Input D Arming (If Source = User Configured) | 0 (Arming) |
| 323 | Digital Input D Activation Delay (If Source = User Configured) | 0:00 |
| 324 | Analogue Input A Sensor Type | 0 (Sensor Type) |
| 325 | Analogue Input A Sensor Selection (Pressure Sensor List) | 0 (Pressure Sensor) |
| 326 | Analogue Input A (Set As Digital) Source (Oil Pressure Sender) | 0 (Input Source) |
| 327 | Analogue Input A (Set As Digital) Polarity | 0 (Polarity) |
| 328 | Analogue Input A (Set As Digital) Action (If Source = User Configured) | 0 (Action) |
| 329 | Analogue Input A (Set As Digital) Arming (If Source = User Configured) | 0 (Arming) |
| 330 | Analogue Input A (set as digital) activation delay (if source = user Configured) | 0:00 |
| 331 | Analogue Input B Sensor Type | 0 (Sensor Type) |
| 332 | Analogue Input B Sensor Selection (Temperature Sensor List) | 0 (Temp Sensor) |
| 333 | Analogue Input B (Set As Digital) Source (Temperature Sender) | 0 (Input Source) |
| 334 | Analogue Input B Polarity (Set As Digital) | 0 (Polarity) |
| 335 | Analogue Input B (Set As Digital) Action (If Source = User Configured) | 0 (Action) |
| 336 | Analogue Input B (Set As Digital) Arming (If Source = User Configured) | 0 (Arming) |
| 337 | Analogue Input B (Set As Digital) Activation Delay (If Source = User Configured) | 0:00 |
| 338 | Analogue Input C Sensor Type | 0 (Sensor Type) |
| 339 | Analogue Input C Sensor Selection (Pressure / Temp / Percentage) | 0 (Sensor) |
| 340 | Analogue Input C (Set As Digital) Source (Flexible Sender) | 0 (Input Source) |
| 341 | Analogue Input C (Set As Digital) Polarity | 0 (Polarity) |
| 342 | Analogue Input C (Set As Digital) Action (If Source = User Configured) | 0 (Action) |
| 343 | Analogue Input C (Set As Digital) Arming (If Source = User Configured) | 0 (Arming) |
| 344 | Analogue Input C (Set As Digital) Activation Delay (If Source = User Configured) | 0:00 |
| 345 | Oil Pressure Sender Open Circuit Alarm | On (1), Off (0) |
| 346 | Temperature Sender Open Circuit Alarm | On (1), Off (0) |

Front Panel Configuration

CONFIGURATION PARAMETERS – OUTPUTS (PAGE 4)

| | | | |
|-----|---------------------------|----------------------------|---|
| 401 | Digital Output A Source | 0 (Output Source) | |
| 402 | Digital Output A Polarity | 0 (Output Source Polarity) | |
| 403 | Digital Output B Source | 0 (Output Source) | |
| 404 | Digital Output B Polarity | 0 (Output Source Polarity) | |
| 405 | Digital Output C Source | 0 (Output Source) | |
| 406 | Digital Output C Polarity | 0 (Output Source Polarity) | |
| 407 | Digital Output D Source | 0 (Output Source) | |
| 408 | Digital Output D Polarity | 0 (Output Source Polarity) | |
| 409 | Digital Output E Source | 0 (Output Source) |  |
| 410 | Digital Output E Polarity | 0 (Output Source Polarity) |  |
| 411 | Digital Output F Source | 0 (Output Source) |  |
| 412 | Digital Output F Polarity | 0 (Output Source Polarity) |  |








 **NOTE:**  = DSE4520 ONLY



Input and Output Configuration Tables are Included Elsewhere in this Section.

CONFIGURATION PARAMETERS – TIMERS (PAGE 5)

| | | | | | |
|-----|-----------------------|-----|---------------------------|-----|-----------------------|
| 501 | Mains Transient Delay | 509 | Warm Up Time | 517 | Breaker Close Pulse |
| 502 | Start Delay | 510 | Return Delay | 518 | Delayed Load 1 |
| 503 | Preheat Timer | 511 | Cooling Time | 519 | Delayed Load 2 |
| 504 | Crank Time | 512 | ETS Solenoid Hold | 520 | Delayed Load 3 |
| 505 | Crank Rest Time | 513 | Failed To Stop Delay | 521 | Delayed Load 4 |
| 506 | Smoke Limiting | 514 | Generator Transient Delay | 522 | Power Save Mode Delay |
| 507 | Smoke Limiting Off | 515 | Transfer Time | 523 | Deep Sleep Mode Delay |
| 508 | Safety On Delay | 516 | Breaker Trip Pulse | 524 | Page Timer |

CONFIGURATION PARAMETERS – GENERATOR (PAGE 6)

| | | | | | |
|-----|---------------------------------|-----------------|-----|-----------------------------------|---|
| 601 | Alternator Fitted | On (1), Off (0) | 617 | Reserved | |
| 602 | Alternator Poles | 0 | 618 | Loading Frequency | 0.0 Hz |
| 603 | Under Voltage Shutdown Enable | On (1), Off (0) | 619 | Nominal Frequency | 0.0 Hz |
| 604 | Under Voltage Trip Shutdown | 0 V | 620 | Over Frequency Warning Enable | On (1), Off (0) |
| 605 | Under Voltage Warning Enable | On (1), Off (0) | 621 | Over Freq Warning Warning Return | 0.0 Hz |
| 606 | Under Voltage Warning Trip | 0 V | 622 | Over Frequency Warning Trip | 0.0 Hz |
| 607 | Reserved | | 623 | Over Frequency Shutdown Enable | On (1), Off (0) |
| 608 | Loading Voltage | 0 V | 624 | Over Frequency Shutdown Trip | 0.0 Hz |
| 609 | Over Voltage Warning Enable | On (1), Off (0) | 625 | AC System | 0 (AC System) |
| 610 | Over Voltage Warning Return | 0 V | 626 | CT Primary | 0 Amps  |
| 611 | Over Voltage Warning Trip | 0 V | 627 | Full Load Rating | 0 Amps  |
| 612 | Over Voltage Shutdown Trip | 0 V | 628 | Immediate Over Current Enable | On (1), Off (0)  |
| 613 | Under Frequency Shutdown Enable | On (1), Off (0) | 629 | Delayed Over Current Alarm Enable | On (1), Off (0)  |
| 614 | Under Frequency Shutdown Trip | 0.0 Hz | 630 | Delayed Over Current Alarm Action | 0 (Action)  |
| 615 | Under Frequency Warning Enable | On (1), Off (0) | 631 | Delay Over Current Time | 0:00:00  |
| 616 | Under Frequency Warning Trip | 0.0 Hz | 632 | Delayed Over Current Trip Level | 0 %  |

 **NOTE:**  = 4510-02 / 4520-02 ONLY

CONFIGURATION PARAMETERS – MAINS (PAGE 7 – DSE4520 ONLY)



| | | | | | |
|-----|-------------------------|-----------------------|-----|-------------------------|-----------------|
| 701 | AC System | AC System (See Table) | 709 | Over Voltage Level Trip | 0 V |
| 702 | Mains Failure Detection | On (1), Off (0) | 710 | Under Frequency Enable | On (1), Off (0) |
| 703 | Immediate Mains Dropout | On (1), Off (0) | 711 | Under Frequency Trip | 0.0 Hz |
| 704 | Under Voltage Enable | On (1), Off (0) | 712 | Under Frequency Return | 0.0 Hz |
| 705 | Under Voltage Level | 0 V | 713 | Over Frequency Enable | On (1), Off (0) |
| 706 | Under Voltage Return | 0 V | 714 | Over Frequency Return | 0 Hz |
| 707 | Over Voltage Enable | On (1), Off (0) | 715 | Over Frequency Trip | 0.0 Hz |
| 708 | Over Voltage Return | 0 V | | | |

Front Panel Configuration

| CONFIGURATION PARAMETERS – ENGINE (PAGE 8) | | |
|--|--|-----------------|
| 801 | Start Attempts | 0 |
| 802 | Overspeed Overshoot | 0 % |
| 803 | Overspeed Delay | 0 s |
| 804 | Gas Choke Timer (Gas Engine Only) | 0 s |
| 805 | Gas On Delay (Gas Engine Only) | 0 s |
| 806 | Gas Ignition Off Delay (Gas Engine Only) | 0 s |
| 807 | Crank Disconnect On Oil Pressure Enable | On (1), Off (0) |
| 808 | Check Oil Pressure Prior To Starting | On (1), Off (0) |
| 809 | Crank Disconnect On Oil Threshold | 0.00 Bar |
| 810 | Crank Disconnect On Frequency | 0.0 Hz |
| 811 | Crank Disconnect On Engine Speed | 0000 rpm |
| 812 | Under Speed Enable | On (1), Off (0) |
| 813 | Under Speed Trip | 0000 rpm |
| 814 | Over Speed Trip | 0000 rpm |
| 815 | Low Battery Volts Enable | On (1), Off (0) |
| 816 | Low Battery Volts Trip | 00.0 V |
| 817 | Low Battery Volts Return | 00.0 V |
| 818 | Low Battery Volts Delay | 0:00:00 |
| 819 | High Battery Volts Enable | On (1), Off (0) |
| 820 | High Battery Volts Return | 00.0 V |
| 821 | High Battery Volts Trip | 00.0 V |
| 822 | High Battery Volts Warning Delay | 00.0 V |
| 823 | Charge Alt Shutdown Enable | On (1), Off (0) |
| 824 | Charge Alt Shutdown Trip | 00.0 V |
| 825 | Charge Alt Shutdown Trip Delay | 0:00:00 |
| 826 | Charge Alt Warning Trip Enable | On (1), Off (0) |
| 827 | Charge Alt Warning Trip | 00.0 V |
| 828 | Charge Alt Warning Trip Delay | 0:00:00 |
| 829 | Low Battery Start Arming | On (1), Off (0) |
| 830 | Low Battery Start Threshold | 00.0 V |
| 831 | Low Battery Start Delay | 0:00:00 |
| 832 | Low Battery Start Run Time | 0:00:00 |

Front Panel Configuration

| CONFIGURATION PARAMETERS – ALTERNATIVE CONFIGURATION (PAGE 9) | | | |
|---|---|---------------------------|---|
| 901 | Default Configuration | Main (1), Alternative (0) | |
| 902 | Alternative Configuration – Enable Configuration | On (1), Off (0) | |
| 903 | Alternative Configuration – Alternative Engine Speed | On (1), Off (0) | |
| 904 | Alternative Configuration – Under Voltage Shutdown Enable | On (1), Off (0) | |
| 905 | Alternative Configuration – Under Voltage Shutdown Trip | 0 V | |
| 906 | Alternative Configuration – Under Voltage Warning Enable | On (1), Off (0) | |
| 907 | Alternative Configuration – Under Voltage Warning Trip | 0 V | |
| 908 | Alternative Configuration – Under Voltage Warning Return | 0 V | |
| 909 | Alternative Configuration – Loading Voltage | 0 V | |
| 910 | Alternative Configuration – Over Voltage Warning Enabled | On (1), Off (0) | |
| 911 | Alternative Configuration – Over Voltage Warning Trip | 0 V | |
| 912 | Alternative Configuration – Over Voltage Warning Return | 0 V | |
| 913 | Alternative Configuration – Over Voltage Trip | 0 V | |
| 914 | Alternative Configuration – Under Frequency Shutdown Enable | On (1), Off (0) | |
| 915 | Alternative Configuration – Under Frequency Shutdown Trip | 0.0 Hz | |
| 916 | Alternative Configuration – Under Freq Warning Enable | On (1), Off (0) | |
| 917 | Alternative Configuration – Under Frequency Warning Trip | 0.0 Hz | |
| 918 | Reserved | | |
| 919 | Alternative Configuration – Loading Frequency | 0.0 Hz | |
| 920 | Alternative Configuration – Nominal Frequency | 0.0 Hz | |
| 921 | Alternative Configuration – Over Frequency Warning Enable | On (1), Off (0) | |
| 922 | Alternative Configuration – Over Frequency Warning Trip | 0.0 Hz | |
| 923 | Alternative Configuration – Over Frequency Warning Return | 0.0 Hz | |
| 924 | Alternative Configuration – Over Frequency Shutdown Enable | On (1), Off (0) | |
| 925 | Alternative Configuration – Over Frequency Shutdown Trip | 0.0 Hz | |
| 926 | Alternative Configuration – CT Primary | 0 Amps |  |
| 927 | Alternative Configuration – Current Full Load Rating | 0 Amps |  |
| 928 | Alternative Configuration – Current Immediate Overcurrent Enable | On (1), Off (0) |  |
| 929 | Alternative Configuration – Current Delayed Alarm Enable | On (1), Off (0) |  |
| 930 | Alternative Configuration – Current Delayed Alarm Action | 0 (Action) |  |
| 931 | Alternative Configuration – Current Delay Timer | 0:00:00 |  |
| 932 | Alternative Configuration – Current Trip % | 0 % |  |
| 933 | Alternative Configuration – AC System | AC System (See Table) | |
| 934 | Alternative Configuration – Mains Failure Detection | On (1), Off (0) |  |
| 935 | Alternative Configuration – Immediate Mains Dropout | On (1), Off (0) |  |
| 936 | Alternative Configuration – Mains Under Voltage Enable | On (1), Off (0) |  |
| 937 | Alternative Configuration – Mains Under Voltage Trip Level | 0 V |  |
| 938 | Alternative Configuration – Mains Under Volt Return | 0V |  |
| 939 | Alternative Configuration – Mains Over Volt Enable | On (1), Off (0) |  |
| 940 | Alternative Configuration – Mains Over Volt Return | 0V |  |
| 941 | Alternative Configuration – Mains Over Volt Trip | 0V |  |
| 942 | Alternative Configuration – Mains Under Frequency Enable | On (1), Off (0) |  |
| 943 | Alternative Configuration – Mains Under Frequency Trip | 0.0 Hz |  |
| 944 | Alternative Configuration – Mains Under Frequency Return | 0.0 Hz |  |
| 945 | Alternative Configuration – Mains Over Frequency Enable | On (1), Off (0) |  |
| 946 | Alternative Configuration – Mains Over Frequency Return | 0.0 Hz |  |
| 947 | Alternative Configuration – Mains Over Frequency Trip | 0.0 Hz |  |
| 948 | Alternative Configuration – Alternative Under Speed Shutdown Enable | On (1), Off (0) | |
| 949 | Alternative Configuration – Alternative Under Speed Shutdown Trip | 0000 rpm | |
| 950 | Alternative Configuration – Alternative Overspeed Shutdown Trip | 0000 rpm | |

 **NOTE:**  = 4510-02 / 4520-02 ONLY

 **NOTE:**  = DSE4520 ONLY

Front Panel Configuration

CONFIGURATION PARAMETERS – FLEXIBLE SENSOR (PAGE 10)

| | | |
|------|---|-----------------------|
| 1001 | Flexible Sensor Alarm Arming | 0 (Arming) |
| 1002 | Flexible Sensor - Low Alarm Enable | 0 (Action) |
| 1003 | Flexible Sensor - Low Alarm Trip (Units Depend Upon Sensor Type) | 0 % / 0.00 Bar / 0 °C |
| 1004 | Flexible Sensor - High Alarm Enable | 0 (Action) |
| 1005 | Flexible Sensor - High Alarm Trip (Units Depend Upon Sensor Type) | 0 % / 0.00 Bar / 0 °C |

CONFIGURATION PARAMETERS – SCHEDULER (PAGE 11)

| | | | | | |
|------|---------------------|-----------------|------|----------|-------------------|
| 1101 | Enable Scheduler | On (1), Off (0) | 1104 | Day | 0 (Day, 1=Monday) |
| 1102 | On Load or Off Load | On (1), Off (0) | 1105 | Duration | 0:00:00 |
| 1103 | Start Time | 0:00:00 | 1106 | Week | 1,2,3,4 |





CONFIGURATION PARAMETERS – TIME AND DAY (PAGE 12)

| | | | | | |
|------|-------------|-------------------|------|--------------|------|
| 1201 | Time Of Day | 0:00 | 1203 | Week Of Year | 1-52 |
| 1202 | Day Of Week | (0 Day, 1=Monday) | | | |

CONFIGURATION PARAMETERS – MAINTENANCE (PAGE 13)

| | | |
|------|---------------------------------------|-----------------|
| 1301 | Maintenance Alarm (Oil) Enable | On (1), Off (0) |
| 1302 | Maintenance Alarm (Oil) Action | 0 (Action) |
| 1303 | Maintenance Alarm (Oil) Engine Hours | 0:00 |
| 1304 | Maintenance Alarm (Air) Enable | On (1), Off (0) |
| 1305 | Maintenance Alarm (Air) Action | 0 (Action) |
| 1306 | Maintenance Alarm (Air) Engine Hours | 0:00 |
| 1307 | Maintenance Alarm (Fuel) Enable | On (1), Off (0) |
| 1308 | Maintenance Alarm (fuel) Action | 0 (Action) |
| 1309 | Maintenance Alarm (fuel) Engine hours | 0:00 |

INPUT SOURCE LIST

| | | | | | | | |
|---|----------------------------|---|----|--------------------------|---|----|------------------------|
| 0 | User Configured | | 10 | Generator load Inhibit | | 20 | Simulate Start button |
| 1 | Alarm Mute | | 11 | Lamp Test | | 21 | Smoke Limiting |
| 2 | Alarm Reset | | 12 | Low Fuel Level Switch | | 22 | Close Gen / Open Mains |
| 3 | Alternative Configuration | | 13 | Mains Load Inhibit |  | 23 | Close Mains / Open Gen |
| 4 | Auto Restore Inhibit |  | 14 | Oil Pressure Switch | | 24 | Maintenance Reset Air |
| 5 | Auto Start Inhibit | | 15 | Remote Start Off Load | | 25 | Maintenance Reset Fuel |
| 6 | Auxiliary Mains Fail |  | 16 | Remote Start On Load | | 26 | Maintenance Reset Oil |
| 7 | Coolant Temperature Switch | | 17 | Simulate Mains Available |  | | |
| 8 | Emergency Stop | | 18 | Simulate Stop button | | | |
| 9 | External Panel Lock | | 19 | Simulate Auto button | | | |

 **NOTE:**  = DSE4520 ONLY

Front Panel Configuration

| INPUT ACTION LIST | |
|-------------------|-----------------|
| Index | Action |
| 0 | Electrical Trip |
| 1 | Shutdown |
| 2 | Warning |

| INPUT POLARITY LIST | |
|---------------------|-------------------|
| Index | Action |
| 0 | Close to Activate |
| 1 | Open to Activate |

| FLEXIBLE SENSOR ALARM ACTION LIST | |
|-----------------------------------|-----------------|
| Index | Type |
| 0 | None |
| 1 | Shutdown |
| 2 | Electrical Trip |

| FLEXIBLE SENSOR TYPE LIST | |
|---------------------------|--------------------|
| Index | Type |
| 0 | None |
| 1 | Digital Input |
| 2 | Percentage Sensor |
| 3 | Pressure Sensor |
| 4 | Temperature Sensor |

| INPUT ARMING LIST | |
|-------------------|----------------|
| Index | Arming |
| 0 | Always |
| 1 | From Safety On |
| 2 | From Starting |
| 3 | Never |

| OUTPUT POLARITY LIST | |
|----------------------|-------------|
| Index | Arming |
| 0 | Energise |
| 1 | De-energise |

| AC SYSTEM LIST | |
|----------------|------------------------|
| Index | Type |
| 0 | 2 Phase 3 wire (L1-L2) |
| 1 | 2 phase 3 wire (L1-L3) |
| 2 | 3 phase 3 wire |
| 3 | 3 phase 4 wire |
| 4 | 3 phase 4 wire (Delta) |
| 5 | Single Phase 2 wire |




| POWER UP MODE | |
|---------------|--------|
| Index | Mode |
| 0 | Stop |
| 1 | Manual |
| 2 | Auto |







| SENSOR SELECTIONS FOR PERCENTAGE | |
|----------------------------------|---------------------------------|
| 0 | Not Used |
| 1 | Digital switch Closed for Alarm |
| 2 | Digital switch Open for Alarm |
| 3 | VDO ohm (10-180) |
| 4 | VDO Tube (90-0) |
| 5 | US ohm (240-33) |
| 6 | GM ohm (0-90) |
| 7 | GM ohm (0-30) |
| 8 | Ford (73-10) |
| 9 | User Defined |



| SENSOR SELECTIONS FOR OIL PRESSURE | |
|------------------------------------|---------------------------------|
| 0 | Not used |
| 1 | Digital switch Closed for Alarm |
| 2 | Digital switch Open for Alarm |
| 3 | VDO 5 bar |
| 4 | VDO 10 bar |
| 5 | Datcon 5 bar |
| 6 | Datcon 10 bar |
| 7 | Datcon 7 bar |
| 8 | Murphy 7 bar |
| 9 | CMB812 |
| 10 | Veglia |
| 11 | User Defined |

| SENSOR SELECTIONS FOR COOLANT TEMPERATURE | |
|---|---------------------------------|
| 0 | Not Used |
| 1 | Digital switch Closed for Alarm |
| 2 | Digital switch Open for Alarm |
| 3 | VDO 120 °C |
| 4 | Datcon High |
| 5 | Datcon Low |
| 6 | Murphy |
| 7 | Cummins |
| 8 | PT100 |
| 9 | Veglia |
| 10 | Beru |
| 11 | User Defined |

Front Panel Configuration




| OUTPUT SOURCE LIST | | |
|--------------------|------------------------------------|---|
| 0 | Not Used | |
| 1 | Air Flap Relay | |
| 2 | Audible Alarm | |
| 3 | Battery Over Volts Warning | |
| 4 | Battery Under Volts Warning | |
| 5 | CAN ECU Data Fail | |
| 6 | CAN ECU Warning | |
| 7 | CAN ECU Shutdown | |
| 8 | CAN ECU Power | |
| 9 | CAN ECU Stop | |
| 10 | Charge Alternator Shutdown | |
| 11 | Charge Alternator Warning | |
| 12 | Close Gen Output | |
| 13 | Close Gen Output Pulse | |
| 14 | Close Mains Output |  |
| 15 | Close Mains Output Pulse |  |
| 16 | Combined Mains Failure |  |
| 17 | Common Alarm | |
| 18 | Common Electrical Trip | |
| 19 | Common Shutdown | |
| 20 | Common Warning | |
| 21 | Cooling Down | |
| 22 | Digital Input A | |
| 23 | Digital Input B | |
| 24 | Digital Input C | |
| 25 | Digital Input D | |
| 26 | Digital Input E (Analogue Input A) | |
| 27 | Digital Input F (Analogue Input B) | |
| 28 | Digital Input G (Analogue Input C) | |
| 29 | Emergency Stop | |
| 30 | Energise to Stop | |
| 31 | Fail to Start | |
| 32 | Fail to Stop | |
| 33 | Fuel Relay | |
| 34 | Gas Choke On | |
| 35 | Gas Ignition | |
| 36 | Generator Available | |
| 37 | Generator Over Voltage Shutdown | |
| 38 | Generator Under Voltage shutdown | |
| 39 | Generator Overcurrent | |
| 40 | Generator Delayed Over Current | |
| 41 | High Coolant Temperature Shutdown | |

| OUTPUT SOURCE LIST | | |
|--------------------|------------------------------------|---|
| 42 | Low Fuel Level | |
| 43 | Low Oil Pressure Shutdown | |
| 44 | Mains High frequency |  |
| 45 | Mains High Voltage |  |
| 46 | Mains Low Frequency |  |
| 47 | Mains Low Voltage |  |
| 48 | Oil pressure Open Circuit | |
| 49 | Open Gen Output | |
| 50 | Open Gen Output Pulse | |
| 51 | Open Mains Output |  |
| 52 | Open Mains Output Pulse |  |
| 53 | Over Frequency Shutdown | |
| 54 | Overspeed Shutdown | |
| 55 | Preheat During Preheat Timer | |
| 56 | Preheat Until End Of Crank | |
| 57 | Preheat Until End Of Safety Timer | |
| 58 | Preheat Until End Of Warming Timer | |
| 59 | Smoke Limiting | |
| 60 | Start Relay | |
| 61 | Temperature Sender Open Circuit | |
| 62 | Under Frequency Shutdown | |
| 63 | Under Speed Shutdown | |
| 64 | Waiting for Manual Restore | |
| 65 | Flexible Sender High Shutdown | |
| 66 | Flexible Sender High Warning | |
| 67 | Flexible Sender Low Warning | |
| 68 | Flexible Sender Low Shutdown | |
| 69 | Delayed Load Output 1 | |
| 70 | Delayed Load Output 2 | |
| 71 | Delayed Load Output 3 | |
| 72 | Delayed Load Output 4 | |
| 73 | Air Filter Maintenance Output | |
| 74 | Oil Filter Maintenance Output | |
| 75 | Fuel Filter Maintenance Output | |
| 76 | Stop Mode | |
| 77 | Auto Mode | |
| 78 | Manual Mode | |

 **NOTE:**  = DSE4520 ONLY

9.3 PRE-COMMISSIONING

Before the system is started, it is recommended that the following checks are made:-

- The unit is adequately cooled and all the wiring to the module is of a standard and rating compatible with the system. Check all mechanical parts are fitted correctly and that all electrical connections (including earths) are sound.
- The unit **DC** supply is fused and connected to the battery and that it is of the correct polarity.
- The Emergency Stop input (if configured) must be wired to an external **normally closed** switch connected to **DC Negative**
- To check the start cycle operation, take appropriate measures to prevent the engine from starting (disable the operation of the fuel solenoid). After a visual inspection to ensure it is safe to proceed, connect the battery supply. Press  the unit start sequence will commence.
- The starter will engage and operate for the pre-set crank period. After the starter motor has attempted to start the engine for the pre-set number of attempts, the LCD will display 'Failed to start. Select the  position to reset the unit.
- Restore the engine to operational status (reconnect the fuel solenoid). Press . This time the engine should start and the starter motor should disengage automatically. If not then check that the engine is fully operational (fuel available, etc.) and that the fuel solenoid is operating. The engine should now run up to operating speed. If not, and an alarm is present, check the alarm condition for validity, then check input wiring. The engine should continue to run for an indefinite period. It will be possible at this time to view the engine and alternator parameters - refer to the 'Description of Controls' section of this manual.
- Initiate an automatic start by supplying the remote start signal (if configured). The start sequence will commence and the engine will run up to operational speed. Once the generator is available a load transfer will take place (if configured), the Generator will accept the load. If not, check the wiring to the Generator Contactor (*if used*). Check the Warming timer has timed out.
- Remove the remote start signal. The return sequence will begin. After the pre-set time, the generator is unloaded. The generator will then run for the pre-set cooling down period, then shutdown into its standby mode.
- Set the modules internal clock/calendar to ensure correct operation of the scheduler and event logging functions. For details of this procedure see section entitled *Front Panel Configuration* .
- If, despite repeated checking of the connections between the controller and the customer's system, satisfactory operation cannot be achieved, then the customer is requested to contact the factory for further advice on:-

INTERNATIONAL TEL: +44 (0) 1723 890099

INTERNATIONAL FAX: +44 (0) 1723 893303

E-mail: Support@Deepseapl.com

Website : www.deepseapl.com

10 FAULT FINDING

| SYMPTOM | POSSIBLE REMEDY |
|--|--|
| Unit is inoperative | Check the battery and wiring to the unit. Check the DC supply. Check the DC fuse. |
| Read/Write configuration does not operate | |
| Unit shuts down | Check DC supply voltage is not above 35 Volts or below 9 Volts Check the operating temperature is not above 70°C. Check the DC fuse. |
| Unit locks out on Emergency Stop | Check emergency stop switch is functioning correctly. Check Wiring is not open circuit.(if configured) |
| Low oil Pressure fault operates after engine has fired | Check engine oil pressure. Check oil pressure switch/sensor and wiring. Check configured polarity (if applicable) is correct (i.e. Normally Open or Normally Closed) or that sensor is compatible with the module and is correctly configured. |
| High engine temperature fault operates after engine has fired. | Check engine temperature. Check switch/sensor and wiring. Check configured polarity (if applicable) is correct (i.e. Normally Open or Normally Closed) or that sensor is compatible with the module. |
| Shutdown fault operates | Check relevant switch and wiring of fault indicated on LCD display. Check configuration of input. |
| Warning fault operates | Check relevant switch and wiring of fault indicated on LCD display. Check configuration of input. |
| Fail to Start is activated after pre-set number of attempts to start | Check wiring of fuel solenoid. Check fuel. Check battery supply. Check battery supply is present on the Fuel output of the module. Check the speed-sensing signal is present on the module inputs. Refer to engine manual. |
| Continuous starting of generator when in AUTO | Check that there is no signal present on the "Remote Start" input. Check configured polarity is correct. |
| Generator fails to start on receipt of Remote Start signal. | Check Start Delay timer has timed out. Check signal is on "Remote Start" input. Confirm correct configuration of input is configured to be used as "Remote Start". Check that the oil pressure switch or sensor is indicating low oil pressure to the controller. Depending upon configuration, the set will not start if oil pressure is not low. |
| Pre-heat inoperative | Check wiring to engine heater plugs. Check battery supply. Check battery supply is present on the Pre-heat output of module. Check pre-heat configuration is correct. |
| Starter motor inoperative | Check wiring to starter solenoid. Check battery supply. Check battery supply is present on the Starter output of module. Ensure that the Emergency Stop input is at Positive. Ensure oil pressure switch or sensor is indicating the "low oil pressure" state to the controller. |
| Engine runs but generator will not take load | Check Warm up timer has timed out. Ensure generator load inhibit signal is not present on the module inputs. Check connections to the switching device. Note that the set will not take load in manual mode unless there is an active remote start on load signal. |

| SYMPTOM | POSSIBLE REMEDY |
|---|---|
| Incorrect reading on Engine gauges Fail to stop alarm when engine is at rest | Check engine is operating correctly. Check sensor and wiring. |
| Set will not take load | Ensure the generator is available. Check that the output configuration is correct to drive the load switch device and that all connections are correct. Remember that the set will not take load in manual mode unless a remote start on load input is present. |
| Inaccurate generator measurements on controller display | The controller is true RMS measuring so gives more accurate display when compared with an 'average' meter such as an analogue panel meter or some lower specified digital multimeters. Accuracy of the controller is better than 1% of full scale. ie Gen volts full scale is 415V ph-n so accuracy is $\pm 4.15V$ (1% of 415V). |

10.1 CAN

| SYMPTOM | POSSIBLE REMEDY |
|---------------|--|
| CAN DATA FAIL | Indicates failure of the CAN data link to the engine ECU. Check all wiring and termination resistors (if required). Check the ECU OVERRIDE function detailed in the section entitled OPERATION elsewhere in this manual. |


10.2 INSTRUMENTS

| SYMPTOM | POSSIBLE REMEDY |
|---|---|
| Inaccurate generator measurements on controller display | Check that the CT primary, CT secondary and VT ratio settings are correct for the application. Check that the CTs are wired correctly with regards to the direction of current flow (p1,p2 and s1,s2) and additionally ensure that CTs are connected to the correct phase (errors will occur if CT1 is connected to phase 2). Remember to consider the power factor. ie $kW = kVA \times \text{powerfactor}$ The controller is true RMS measuring so gives more accurate display when compared with an 'averaging' meter such as an analogue panel meter or some lower specified digital multimeters. Accuracy of the controller is better than 1% of full scale. ie Gen volts full scale is 415V ph-n so accuracy is $\pm 4.15V$ (1% of 415V). |



NOTE: Current sensing is not available on 4510-01 / 4520-01

10.3 MISCELLANEOUS

| SYMPTOM | POSSIBLE REMEDY |
|--|--|
| Module appears to 'revert' to an earlier configuration | <p>When editing a configuration using the PC software it is vital that the configuration is first 'read' from the controller before editing it. This edited configuration must then be "written" back to the controller for the changes to take effect.</p> <p>When editing a configuration using the fascia editor, be sure to press the  (✓) button to save the change before moving to another item or exiting the fascia editor</p> |

▲ NOTE: The above fault finding is provided as a guide check-list only. As the module can be configured to provide a wide range of different features, always refer to the source of your module configuration if in doubt.

11 MAINTENANCE, SPARES, REPAIR AND SERVICING

The controller is *Fit and Forget*. As such, there are no user serviceable parts within the controller. In the case of malfunction, you should contact your original equipment manufacturer (OEM).


11.1 PURCHASING ADDITIONAL CONNECTOR PLUGS FROM DSE

If you require additional plugs from DSE, please contact our Sales department using the part numbers below.


11.1.1 PACK OF PLUGS

| Module type | Plug Pack Part Number |
|-------------|-----------------------|
| 4510-01 | 100-400-41 |
| 4520-01 | 100-400-42 |
| 4510-02 | 100-400-47 |
| 4520-02 | 100-400-46 |


11.1.2 INDIVIDUAL PLUGS

| Module Terminal Designation | Plug Description | Part No. |
|---|---|----------|
| 1-9 DSE4520 Only | 9 way 5.08mm | 007-166 |
| 1-7 DSE4510 Only | 7 way 5.08mm | 007-155 |
| 10-20 | 11 way 5.08mm | 007-451 |
| 21-24 | 4 way 10.16mm | 007-003 |
| 25-28 DSE4520 Only | 4 way 10.16mm | 007-003 |
| 29-32 Not fitted on 4510-01 / 4520-01 | 4 way 5.08mm | 007-282 |
|  USB | PC Configuration interface lead (USB type A – USB type B) | 016-125 |

11.2 PURCHASING ADDITIONAL FIXING CLIPS FROM DSE

| Item | Description | Part No. |
|---|-----------------------------------|----------|
|  | Module fixing clips (packet of 4) | 020-294 |

11.3 PURCHASING ADDITIONAL SEALING GASKET FROM DSE

| Item | Description | Part No. |
|---|-------------------------------|----------|
|  | Module silicon sealing gasket | 020-507 |

12 WARRANTY

DSE provides limited warranty to the equipment purchaser at the point of sale. For full details of any applicable warranty, you are referred to your original equipment supplier (OEM).

13 DISPOSAL

13.1 WEEE (WASTE ELECTRICAL AND ELECTRONIC EQUIPMENT)

Directive 2002/96/EC

If you use electrical and electronic equipment you must store, collect, treat, recycle and dispose of WEEE separately from your other waste.



13.2 ROHS (RESTRICTION OF HAZARDOUS SUBSTANCES)

Directive 2002/95/EC: 2006

To remove specified hazardous substances (Lead, Mercury, Hexavalent Chromium, Cadmium, PBB & PBDE's)

Exemption Note: Category 9. (Monitoring & Control Instruments) as defined in Annex 1B of the WEEE directive will be exempt from the RoHS legislation. This was confirmed in the August 2005 UK's Department of Trade and Industry RoHS REGULATIONS Guide (Para 11).

Despite this exemption, DSE has been carefully removing all non RoHS compliant components from our supply chain and products.

When this is completed, a Lead Free & RoHS compatible manufacturing process will be phased into DSE production.

This process that is almost complete and is being phased through different product groups.

This Page Is Intentionally Left Blank

This Page Is Intentionally Left Blank